

ROUTICA WIRELESS GATEWAY ROUTER QUICK START GUIDE

EXPLORER I – NO ANTENNA

Step 1: Install the activated SIM card

- The SIM card must be Full size. Micro or Nano size SIM cards are not supported.
- Ensure correct orientation of the SIM card as shown.
- Insert the SIM card into the sim slot and push it in until it clicks into place.

Supported cellular carriers includes:

USA: T-Mobile

Canada: Rogers, Bell, and Telus


Other third-party cellular carriers may also be used.



Step 2: Connect your antennas shown in the illustration below

Wi-Fi Antenna: Impedance: 50 Ohms, Reverse Polarity SMA Plug, Omnidirectional, Frequency 2.4GHz ~ 2.5GHz, 5.15GHz ~ 5.85GHz, VSWR <=2.0 , Gain 4 dBi

Cellular Antenna: Impedance 50 Ohms, SMA Plug, Omnidirectional, Frequency 600 MHz ~ 3800 MHz, VSWR <= 3.0 Gain 5 dBi



Step 3: Apply Power

- Connect the supplied AC/DC power adapter into an AC Outlet. Then connect the 4 Pin DC Power Cable into the Router and plug the DC connector to 4 Pin DC Power Cable.
- When power is successfully applied, the RED power LED will illuminate.
- Wait until the 4G, 5G and 2.4G GREEN LEDs turn on.



ROUTICA WIRELESS GATEWAY ROUTER QUICK START GUIDE

EXPLORER I – NO ANTENNA

Step 4: Wi-Fi Connection

- Scan QR code to the right to set up a connection from your Android/iOS mobile device to your Explorer I Wireless Gateway Router
- The QR code will automatically enter your SSID and the default password.
- Your Explorer I Wireless Gateway Router's SSID's and password are also available on the bottom of your Explorer I.

Affix Wi-Fi

Step 5: Download Routica Mobile Application

- The Explorer I Wireless Gateway Router is set up using your mobile phone. Download the “Routica” application from the Google Play Store (Android) or App store (iPhone).

Scan the QR codes below to download the Routica Mobile App



Android



IOS

Step 6: Verify your installation

- Once installation is complete, follow the instructions for registration and setup.
- After set-up is complete verify that other devices (Smartphones, tablets, etc. can connect to Explorer I Wireless Gateway Router and can access the internet.

Step 7: Close the SIM Slot Cover

- Use the two black screws provided to install the SIM Card Cover.



Step 7

Step 8: Mount your Explorer I Wireless Gateway Router

- We suggest mounting your Explorer I Wireless Gateway Router securely at an appropriate place to prevent damage caused by extreme movement.
- It may be mounted in your chosen location with due consideration to the placement of your selected antenna set and access to a power outlet.



Need further assistance?

Please visit our website www.routica.com